
Doctor of the man of t cases, îĘ. sure to read and understand all instruction sheets completely before beginning assembly or installation.

assembly and installation work must be performed by qualified personnel, in accordance with all applicable national and local building and #.a.

aware that the weight of some fixtures may exceed the strength rating of the 4" electrical junction box or other such hardware at your as the responsibility of the contractor to properly secure the fixture to the structure, and to provide adequate support for the fixture.

to constant production improvements, details of the design, material or finish may change in any way that will not significantly after instalreduce function or performance.



1) Turn power off! Pull the wires out of the junction box and feed them through the center hole in the mounting plate.

Attach the mounting plate to the junction box with the screws provided so your fixture mounts vertically perpendicular to the ceiling.

2) Connect the light fixture wires to the wires in the junction box.

Wire black or brown to line voltage, white or blue to neutral, and attach the green or bare wire to the green ground screw provided on the mounting plate. Use wire nuts on the connections and leave no bare wire exposed (excepting the green). Tuck the wires inside the junction box.

- 3) Secure the light fixture to the mounting plate by lining up the holes on the decorative cover with the threaded holes on the mounting plate and screwing in the flat head screws provided. Make sure to fasten securely.
- 4) Slide the diffuser onto the socket and thread the socket ring onto the socket to hold the diffuser in place. Hand tighten only as the diffuser is fragile.
- 5) Screw the lamp (by others) into the socket inside your fixture. Turn your power back on and you have completed the installation process.

Norwell Lighting

REV.	BY	DATE	DESCRIPTION
·			
IN	ISTI	RUCTION	IS BY, SHEET 1 OF 1
Α	rctic	Bath	
4	/24/	′2019	8282-A-INST
			FILENWE

8282-A-INST